



## Cisco Broadworks Docking Configuration manual



## Catalogue

I	Foreword .....	1
	1.Introduction of Cisco BroadWorks .....	1
	2. Announcements .....	1
II	Configuration Flow .....	2
III	Configuration Operation .....	2
	1. Login the Cisco BroadWroks management web .....	2
	2. Add an extension .....	3
	2.1 Add a new user .....	3
	2.2 Assign an extension number .....	5
	3.Config FIYINGVOICE IP Phones.....	8
	3.1 Fill in the parameters in the web of IP Phone.....	8
	3.2 Save & Apply .....	9
IV	Check Result .....	10



## I Foreword

### 1.Introduction of Cisco BroadWorks


Cisco BroadWorks, as the world's leading cloud business communication platform, not only provides excellent security and reliability, but also guarantees up to 99.999% availability and full redundancy. It has full Cisco Broadworks capabilities and supports more than 26 million enterprise users worldwide, ranging from small and micro businesses to multinational corporations. Based on its open architecture, all series of Fision phones support the automatic deployment service of Cisco Broadworks as SIP server, which eliminates the tedious manual deployment process for users and brings more convenience to users.

### 2. Announcements

This article aims to provide SIP account registration operation guidance for users who use Cisco Broadworks as SIP server and FLYINGVOICE IP phone as terminal.



## II Configuration Flow




## III Configuration Operation

### 1. Login the Cisco BroadWorks management web

Steps:


Browser to enter the address of Cisco BroadWorks --》 Input User ID and password, click on the login.





Copyright © 2020 Cisco and/or its affiliates.  
 PROPRIETARY AND CONFIDENTIAL - ALL USE MUST BE LICENSED.  
 The code, technical concepts, all information contained herein and related documentation are the property of, proprietary to and are vested in Cisco Technology, Inc. and/or its affiliated entities, ("Cisco") under various laws including copyright, international treaties, patent, trade secret and/or contract.  
 Any copying, dissemination, reverse engineering, disclosure or other use of the material contained herein without an express license from Cisco is prohibited and, among other legal consequences, constitutes an infringement of the intellectual property and the proprietary rights of Cisco.

All use of the material herein must be in strict accordance with the terms of the license you have entered into with Cisco. All rights not expressly licensed are reserved.



## 2. Add an extension

Broadworks has a fixed extension allocation mechanism. Each user can only be assigned one extension number, so you can only assign extensions to existing users. If you need to add an additional extension, you need to add a new user.

### Attention:

For the address, user name and password of Cisco BroadWorks, please contact the administrator to obtain it. One extension number will correspond to one user.



### 2.1 Add a new user

Cisco Broadworks has a fixed extension allocation mechanism. Each user can only be assigned one extension



number, so you can only assign extensions to existing users. If you need to add an additional extension, you need to contact your administrator to add a new user. This article will demonstrate the operation of adding a new user (extension number) under the authority of administrator. **Steps:**

**Profile--》Users--》Add--》 Fill in the user information and save the application (the informations with \* are required, and the rest is optional)**



Options:

- Profile
- Resources
- Services
- Call Center
- Utilities

## Users Add

Add a new user to your group.

Enterprise: DevNet
Group: u2454388546-Grp1

\* User ID:  @ broadsoftlab.com

\* Last Name:

\* Calling Line ID Last Name:

Name Dialing Last Name:

\* Initial Password:

Department: None

Time Zone: (GMT+05:30) Asia/Kolkata

\* First Name:

\* Calling Line ID First Name:

Name Dialing First Name:

\* Re-type Initial Password:

Language: English

Network Class of Service: None

Additional Information

Title:

Pager:  Mobile:

E-mail:  YahooID:

Location:

Address:

City:  State/Province: -- Select --

Zip/Postal Code:  Country:

OK
Cancel

**Table1 Parameters Description**

Parameters	Description
<b>User ID</b>	User ID, which is customizable and used as the username to log into Cisco BroadWroks.
<b>Last Name</b>	Enter the user's Last name;
<b>First Name</b>	Enter the user's First name;
<b>Calling Line ID Last Name</b>	The Last name will be displayed on the caller interface when dialing. This parameter follows Last Name by default;
<b>Calling Line ID First Name</b>	When dialing the First name of the caller interface, this parameter follows the First Name by default;
<b>Initial Password</b>	Set the user's initial password.
<b>Re-type Initial Password</b>	Reenter the user's initial password to confirm.

## 2.2 Assign an extension number

To assign an extension to a new user, you need to manually assign an extension to a newly added user, or you can follow this step to change the extension configuration of an existing user.

### Steps:

Filter Users according to specific conditions (if you do not add conditions, directly click Search to display all users by default) -- > Click Edit to config the extension for users --> enter the extension configuration interface, fill in the parameters, see Table 2 for parameters description -- > Apply --> Successful configuration, return to the Users interface to view the extension.



Options:

- Profile
- Resources
- Services
- Call Center
- Utilities

## Users

Add a new user or manage existing users in your department or group.

① OK Add Cancel

Enter search criteria below

User ID  Contains    ③

OK Add Cancel

Options:

- Profile
- Resources
- Services
- Call Center
- Utilities

## Users

Add a new user or manage existing users in your department or group.

OK Add Cancel

Enter search criteria below

User ID  Starts With

User ID	Last Name	First Name	Phone Number	Extension	Department	In Trunk Group	Edit
u9736722341	L9736722341	F9736722341	+1-9736722341	2341			Edit
u9736722342	L9736722342	F9736722342	+1-9736722342	2342			Edit
u9736722343	L9736722343	F9736722343	+1-9736722343	2343			Edit
u9736722344	L9736722344	F9736722344	+1-9736722344	2344			Edit
④ u9736722345	L9736722345	F9736722345	+1-9736722345	2345			Edit
u9736722368	L9736722368	F9736722368					Edit

[ Page 1 of 1 ]

OK Add Cancel

① Cisco

Group > Users - u9736722368

英语 中文 (简体) : X Help - Home

Google Translate

Sandbox [Logout]

Options:

- Profile
- Outgoing Calls
- Communication Barring
- Utilities

## Profile

### Basic

### Profile

② Display and configure profile information such as your name, department and address.

### Addresses

Addresses allows you to view and maintain your phone numbers and other identities that are used to make and receive calls.

### Announcement Repository

Manage the announcements for a user

### Passwords

Set web access and portal passwords.

### Schedules

Add, modify, or remove schedules.

### Advanced

#### Assign Services

Assign or unassign services and service packs.

#### Assign Xsi Policy Profile

Assign a Xsi policy profile for a user.

#### Call Application Policies

Select Call Control Applications enabled for a user.

#### Call Policies

Configure user Call Policies

#### Call Processing Policies

Configure user-level Call Processing Policies

#### Communication Barring Authorization Codes

Configure Communication Barring Authorization codes for a user.

#### Device Policies

Configure user Device Policies.



- Options:
- Profile
  - Outgoing Calls
  - Communication Barring
  - Utilities

## Addresses <sup>6</sup>

Addresses allows you to view and maintain your phone number and other identities that are used to make and receive calls.

OK Apply Cancel

1 Phone Number: 9736722348 | Activated

2 Extension: 2348

3  Identity/Device Profile  Trunking  None

Identity/Device Profile

4 Identity/Device Profile Name: GenericSIP (Group) Configure Identity/Device Profile

5 \* Line/Port: 9736722348 @ broadsoftlab.com | AdvancedSettings

Contact:

sip:	<input type="text"/>	Path:	<input type="text"/>
sip:	<input type="text"/>	Path:	<input type="text"/>
sip:	<input type="text"/>	Path:	<input type="text"/>
sip:	<input type="text"/>	Path:	<input type="text"/>
sip:	<input type="text"/>	Path:	<input type="text"/>

Use Hotline

Hotline Contact:

Aliases: sip: u9736722368@broadsoftlab.com

sip:  @ broadsoftlab.com

sip:  @ broadsoftlab.com

sip:  @ broadsoftlab.com

- Options:
- Profile
  - Resources
  - Services
  - Call Center
  - Utilities

## Users

Add a new user or manage existing users in your department or group.

OK Add Cancel

Enter search criteria below

User ID  Starts With

User ID	Last Name	First Name	Phone Number	Extension	Department	In Trunk Group	Edit
u9736722341	L9736722341	F9736722341	+1-9736722341	2341			Edit
u9736722342	L9736722342	F9736722342	+1-9736722342	2342			Edit
u9736722343	L9736722343	F9736722343	+1-9736722343	2343			Edit
u9736722344	L9736722344	F9736722344	+1-9736722344	2344			Edit
u9736722345	L9736722345	F9736722345	+1-9736722345	2345			Edit
1 u9736722368	L9736722368	F9736722368	+1-9736722348	2348			Edit

[ Page 1 of 1 ]

OK Add Cancel



**Table2 Parameters Description**

Parameters		Description
Phone Number		The phone number assigned to this user, which is immutable and can only be selected from an existing number.
Extension		The extension number assigned to this user, which defaults to the last four digits of the phone number and can be customized.
Identity/Device Profile; Trunking; None;		Choose the authentication method, if you choose to use Identity/Device Profile, you can choose the new template or use the generic SIP template; If Trunking is selected, the number will be added to the relay group. If NONE is selected, no authentication method is set.
Identity/Device Profile	Identity/Device Profile Name	Select a profile name;
	Line/Port	Select a phone line, usually in the form of <b>phone number @domain.com</b> ;
Aliases		Alias control, enter up to three SIP addresses using this number, all of which will eventually be redirected to this number;

### 3.Config FIYINGVOICE IP Phones

#### 3.1 Fill in the parameters in the web of IP Phone

Fill in the extension information on the IP phones and register.

**Attention:**

The password entry in the user information is determined by the Identity/Device Profile of the Cisco BroadWroks.

**Steps:**

Login the web page of the phone -- » Enter configuration information -- » Save and apply -- » Register successfully.



The screenshot shows the 'SIP Account' configuration page for 'Line 1'. The 'Line Enable' dropdown is set to 'Enable'. The 'Subscriber Information' section includes fields for Display Name (u9736722348), Account (u9736722348), Phone Number (9736722348), and Password (masked). The 'SIP Server 1' section includes Proxy Server (broadsoftlab.com), Proxy Port (5060), Register Refresh Interval (1800), and Transport (UDP). The 'Proxy Server' section includes Outbound Server (131.226.217.156), Outbound Port (5683), Backup Outbound Server, and Backup Outbound Port (5060). The 'Save & Apply' button is highlighted with a red box.

Table 3 Parameters Description

Parameters	Description
Display Name	Customizable display name;
Account	Corresponds to the Broadworks User ID;
Password	Corresponding to the password set in Broadworks' Identity/Device Profile;
Phone Number	Corresponds to the Phone Number of Broadworks;
Proxy Server	The domain where the Broadworks Cisco BroadWroks resides.
Proxy Port	Default is 5060;
Outbound Server	IP address of the IP Cisco BroadWroks.
Outbound Port	Corresponds to the port set in Broadworks' Identity/Device Profile.

## 3.2 Save & Apply

Steps: Click Save & Apply.

The screenshot shows the 'RTP Advanced Setup' configuration page. The 'RTP Port Min' is set to 0 (0 means auto select) and 'RTP Port Max' is set to 50000. 'Symmetric RTP' is set to 'Disable'. The 'Save & Apply' button is highlighted with a red box.



Line Status	
Line 1 Status	Registered 9736722348
Primary Server	131.226.217.156
Backup Server	0.0.0.0
Line 2 Status	Disable
Primary Server	0.0.0.0
Backup Server	0.0.0.0

## IV Check Result

Phone number 9736722341 Call phone number 9736722348 for testing.

