


Emergency SOS Button Kit



Quick Guide


HB01 + USB433

www.flyingvoice.com


1 Product Introduction

Flyingvoice SOS Wireless Call Button Kit (HB01+USB433) for FIP12WP/ P2X Series IP Phones, via the combination of USB dongle and SOS button, to realize the wireless call speed dialing, to provide the user with a more convenient and efficient call experience, is the ideal choice for Nurse Calling, Patient Assistance, Home, etc.

2 Packaging List



3 Hardware Introduction




USB Dongle

Status	Description
Plug In	Red and blue LED on when you plug in the USB dongle.
Standby	Red LED blinks every 3s in standby mode.
Received Signal	Blue LED blinks once when dongle receives the signal transmitted by beeper.
Dongle Pairing Mode (Long Press Button for 3s)	LED red is always on: indicates that it has entered the pairing mode. LED blue blinks once: Beeper pairs dongle successfully and automatically exits the learning state; TIPS: Repeat the action if you want to pair the next device.
Phone Pairing Mode (Go to Search Mode)	LED red is always on: indicates that it has entered the pairing mode. LED blue blinking: pager pairing dongle successful, continue to return to pairing mode. TIPS: If no device is detected within 60s in search mode, it will be closed automatically.

4 Feature Configuration

4.1 Plug in USB Dongle

Plug in the USB dongle after the phone is powered up and networked, the phone UI will indicate that USB connected. At this time, the dongle indicator light flashes red and blue, and then goes out.



4.2 Beeper Pairing

a. Go into pairing mode through Phone UI

Step1. Press Menu, then choose Feature > "Beeper" via Phone UI

Step2. Select "Beeper Pairing List", Press "Search" go into pairing mode.

Step3. Press your sos button, Phone UI will add new beeper ID.

Step4. Press "Pair", You can pair more devices, just repeat the step.

Note: If no new device connection is detected for 60s in search mode, the mode will be closed automatically.

Beeper Pairing List		2/8
<input type="radio"/>	03-02-C7	
<input checked="" type="radio"/>	03-02-C8	✓
<input type="radio"/>	03-02-C9	
<input type="radio"/>	03-02-CA	
<input type="radio"/>	03-02-CB	

Back Search Delete Pair

b. Go into pairing mode via dongle

Long press the dongle pairing key for 3s, when RED LED is always on, it goes into the pairing mode; if the pairing is successful, Blue LED flashes once, and it automatically exits the pairing mode.

TIPS: if you need to add more devices, repeat the step.

4.3 Call Settings

You need to configure SpeedDial number before using beeper.

Step1. Press "HELP" key on the FIP12WP Phone or the "M1" key on the P2X Phone, select "SpeedDial" type and Line.

Step2. Type in the SpeedDial number in the value.

Line Key	
1. Type	Speed Dial ▶
2. Account ID	Line 1 ▶
3. Label	
4. Value	1000


Back Confirm

Note: You need to check if Line is registered successfully or if the extensions are under the same server.

4.4 Press Button to Call

By pressing the paired beeper, the phone will automatically call out the pre-set number in the SpeedDial key.

SOS无线呼叫器



快速指南

HB01 + USB433

www.flyingvoice.cn

1 产品简介

飞音时代紧急求助无线呼叫器 (HB01+USB433), 适用于飞音 FIP12WP/ P2X Series IP话机, 通过USB Dongle和呼叫器组合, 实现无线呼叫速拨, 为用户提供更便捷、效率的呼叫体验, 是养老院、居家、医院等场所的理想选择。

2 包装清单



3 硬件介绍



USB Dongle

状态	描述
插入	插入USB, LED红、蓝灯同时亮
待机	待机状态下, LED红灯每隔3s闪烁一下
接收信号	当Dongle接收到呼叫器信号, LED蓝灯闪烁一下
Dongle配对模式 (长按按键3s)	LED红灯常亮: 表示已经进入配对模式 LED蓝灯闪烁: 呼叫器配对Dongle成功, 并自动退出学习状态; TIPS: 若要配对下一个设备, 则需重复该动作。
话机配对模式 (话机按下搜索)	LED红灯常亮: 表示已经进入配对模式 LED蓝灯闪烁: 呼叫器配对Dongle成功, 继续返回配对模式; TIPS: 搜索模式60s内无检测到设备, 则自动关闭

4 功能配置

4.1 插入USB Dongle

话机上电联网后, 插入USB Dongle, 话机UI会提示USB已连接。此时Dongle指示灯红、蓝灯闪烁, 然后熄灭。



4.2 呼叫器配对

a. 通过话机UI打开配对模式查找呼叫器

Step1. 在话机上进入 菜单, 选择 功能 > 呼叫器。

Step2. 选择 "呼叫器配对列表", 点击 "搜索"。

Step3. 按下呼叫器, 话机UI会新增呼叫器的ID号码, 点击 "配对", 您可以多个设备进行配对, 重复该操作即可。

Note: 如果搜索模式下60s无检测到新的设备连接, 搜索模式会自动关闭。

设备配对列表		2/8
<input type="radio"/>	03-02-C7	
<input checked="" type="radio"/>	03-02-C8	
<input type="radio"/>	03-02-C9	
<input type="radio"/>	03-02-CA	
<input type="radio"/>	03-02-CB	
返回	搜索	删除 配对

b. 通过Dongle上的按键进入配对模式

长按Dongle配对键3s, 当红灯常亮, 则进入配对模式; 如果配对成功, 则蓝灯闪烁一次, 然后自动退出配对模式。

TIPS: 如需添加更多设备, 请重复该步骤。

4.3 呼叫设置

在呼叫器使用之前, 你需要配置速拨号码。

Step1. 在FIP12WP话机上长按 "HELP" 键或P2X系列话机上 "M1" 键, 选择 "速拨" 和 Line, 在值中填写速拨号码。

Step2. 在值中填写速拨号码, 选择 "保存"。

按键设置	
1. 类型	速拨
2. 账号ID	Line 1
3. 标签	
4. 值	1000
返回	确认

Note: 您需要检查Line 是否注册成功或分机号是否处于同一服务器上。

4.4 按钮触发呼叫

按下已配对的呼叫器, 话机即可自动呼出速拨键里预设的号码。